



FM-transmitter activation

This activation is only to be used by US customers. If you are not living in US and have bought a Jens of Sweden player and would like to activate the FM-transmitter, we take no responsibility regarding legal issues of using the functionality. **WE DO NOT** recommend activating the function if you are living outside US due to legal reasons. Jens of Sweden cannot under any conditions give support on the FM-transmitter function to customers not staying in US. Still the guarantee and service though always remain on the product.

The activation is made by executing one of the two files:

Activate.exe for activating the function

Deactivate.exe for deactivating the function

Please connect the player to the USB-port and run the **Activate.exe** file, after finishing the activation please disconnect and turn of the player. The player is now activated.

For deactivating please use the same process – run **Deactivate.exe**, the player should be connected to the USB port.

The activation can only be done on a computer with Windows.

Best regards,

Jens of Sweden

JENS OF SWEDEN AB - SKIVFILARGRÄND 4 - 721 30 VÄSTERÅS - SWEDEN
OWNER OF JOS AND JENS OF SWEDEN TRADEMARKS

TELEPHONE +46(0)40-46 58 00
FAX +46(0)40-470 20 58
WEBSITE WWW.JENSOFSWEDEN.COM
EMAIL TEAM@JENSOFSWEDEN.COM
BANKGIRO 5595-7625
POSTGIRO 388323-8

VAT 16556639083601
BANK SWEDBANK, S-105 24 STOCKHOLM
SWIFT CODE: SWEDSESS
TELEX: 128 26 SWEDBNK S
ACCOUNT NO: SE7680000842440370251704